



200W Beam Moving Head Light

USER MANUAL



Please read over this manual before operation the light

Catalogue

Maintenance

Statement

Safety Precautions

Products Instruction

Menu Function

Channels Control

Maintenance

- 1、 To reduce the risk of electrical shock or fire, do not expose this unit to rain or moisture.
- 2、 Do not spill water or other liquids into or on to your unit.
- 3、 During long periods of non-use, disconnect the unit's main power.
- 4、 It should be installed in a well-ventilated place, at a distance of 50 centimeters or more with the walls. At the same time, please check if the fan and ventilation holes are unobstructed

Statement

The product has perfect performance and good packing. All users should be strict comply with the warning and operating instructions as stated. Or we aren't in charge of any result by misusing. Any damage resulting by misuse is not within the Company's warranty. Any fault or problem caused by neglecting the manual is also not in the charge of dealers.

Note: All information is subject to change without prior notice.

Safety Precautions

Beam Moving Head Light

	200-205	Open lamp
	206-255	Reset



ETS Sales & Hire Ltd

Unit 33

Penfold Drive

Wymondham

Norfolk

NR18 0WZ

01953 600888

www.etsnet.co.uk

Beam Moving Head Light

1、 In order to guarantee the product's life, please don't put it in the damp places or even the environment over 60degrees.

2、 Always mount this unit in safe and stable matter.

The qualified professionals are allowed to carry out the lamp installation, operation and maintenance, but they must guarantee to operate in strict accordance with the instructions referred to.

3、 Using lamp , the change rate of Power voltage should be within $\pm 10\%$,

If the voltage is too high , it will shorten the light's life; if it's not enough, the lamp will be dark.

4、 Please restart it after turning off light for 20 minutes until full-cooling. Frequent switching will reduce the life span of lamps and bulbs; intermittent using will improve the life of bulbs and lamps.

5、 In order to make sure the product is used well, please read the Manual carefully.

Products Instruction

- Lamp : philips 5R 189W
- Channel Model : 16 channels ,DMX512
- Pan scan : 540°(16bit) Electric correction
- Tilt scan : 270° (16bit) Electric correction

Beam Moving Head Light

· Color Wheel : 14Color+White , Single rotation rainbow effect, two models changing (Full color and half color operating)

· Prism insertion

· Gobos: 17gobos +white , Double rotation rainbow effect

· Strobe : 13 t/s , free strobe and false strobe

· Frog : 0%~100% linear frog ,

· Nice red spot and full display

· Self developed switch power: lighter, stable, self protect

· Controller can open the light and reset, including delaying function

Voltage: AC110~240V, 50/60HZ

Channels Control:

CH1	0-255	Pan
CH2	0-255	Tilt
CH3	0-255	Pan fine
CH4	0-255	Tilt fine

Beam Moving Head Light

CH5	0-255	Frost
CH6	0-255	Speed of X/Y
CH7	0-240 245-255	Strobe from slow to fast White iris
CH8	0-255	Dimmer
CH9	0-125 126-196 197-255	Color Color plate rotation forward Color plate rotation reverse
CH10	0-255	Color plate half color adjustment
CH11	0-122 123-190 191-255	Gobo Gobo plate rotation forward Gobo plate rotation reverse
CH12	0-190 191-255	Gobo jitter No function
CH13	0-255	Focus
CH14	0-255	Eight prism
CH15	0-255	Prism rotation forward and reverse
CH16	0-99 100-105	No function Close lamp